



**Nelson & Nelson Mfg.**  
5210 Stadium Blvd., Suite C  
Jonesboro AR 72404  
870-268-6393 : Cell 219-1019

Installation Instructions 7-3-24

**Model SF3RT-ACCM**

**2024+ Accessory Mount Left / Right Hand Mounting**

**Steps needed to install your Accessory Mount Kit!**



**Left Side Mount SF3RT-ACCM-L**



**Right Side Mount SF3RT-ACCM-R**



**Left Side Mounting**



### **Right Side Mounting**

**1.- Remove the two 4mm factory Allen screws on the backside of the control module using a 3mm Allen wrench on the side you are mounting the mount. Left & Right sides determined by rider sitting on your Spyder.**

**LEFT SIDE INSTALL-**Then take the preassembled mount as shown for a Left-side mounting using the smaller black spacer on the bottom and the larger black spacer on top. Take the new smaller Allen Head Socket bolt and install it in the lower hole. Take the longer Allen Head socket bolts and install it on the top hole. Tighten down evenly.

**RIGHT SIDE INSTALL-** Then take the preassembled mount as shown for a Right-side mounting using the black spacer on the bottom & top. Take the new Allen Head Socket bolts and install them in the lower & upper holes. Tighten down evenly.

**Your New 2024+ F3 / RT Accessory Mount is installed!**

**We thank you for purchasing one of our Spyder Extras RT Products. We know today the needs for accessories that provide a higher level of comfort while riding and we have solved that demand with a stylish Products that complement the design of your F3 or RT !**

**[spyderextras.com](https://spyderextras.com)**