



**Nelson & Nelson Mfg.**  
5210 Stadium Blvd, Suite C  
Jonesboro AR 72404  
870-268-6393 : Cell 219-1019

Installation Instructions 9-23-24

**Model SF3-RCK**  
**SF3-SF3S-F3T Rear Carrying Rack**

**Steps needed to install your SF3 Carrying Rack**



1.- First locate on each side of the two main rear grab bar bolts as shown below. Using a 6mm Allen wrench remove these 2 bolts from each side. When you remove them watch the back side of the grab bar each bolt location to make sure the metal washer does not fall out.



2.-Next take the supplied new bolts with washer and the supplied spacer and locate the rack with each side arm located over the two bolt locations each side. Place the spacer in the bolt location as shown below and move the rack in place. Often it helps to have another person hold the rack while you install all 4 bolts.

Using the supplied bolt, place the bolt in the rack mounting hole through the spacer and just tighten slightly. When doing so be aware to locate the rear factory washer so the bolt you are installing goes through that washer into the threaded frame correctly. Do the same for all 4 bolts.



3.- Once all 4 bolts are tightened then take the supplied rubber caps and place over the socket head of each bolt. This completes the installation of your new F3 Rear Carrying Rack. Your Rack can easily carry 20 lbs. of weight.



We thank you for purchasing one of our Spyder F3 Carrying Rack Kits. Today we know the needs for accessories that provide a higher level of Style and Design and we have solved that demand with a stylish system that compliments the design of your Spyder F3®!

[spyderextras.com](http://spyderextras.com)